

Basics of Reverberant Noise Control

By Paul L. Battaglia, AIA, ASA, INC
October 30, 2017

Reverberation is very recognizable in a big space, especially when it's excessive. People refer to such a room as "echoey" or simply too noisy. Sounds that are introduced into the space (impulse) seem to linger for a little while before diminishing to a level where they aren't heard. It's a characteristic measured in seconds and termed *Reverberation Time*.

When sounds linger in a space the *subsequent* sounds that are introduced, as in speech, are partially covered over by the *previous* sounds and not as easily understood. This is sometimes desirable, such as for music that is based in harmony, so spaces for different types of music have various recommended reverberation times. Spaces for *acoustical comfort* and for *speech* should have *low* reverberation times of 0.9 second or less. *Low reverberation time reduces reverberant noise levels and assists sound recognition.*



Figure 1: Wallace Sabine

The concept of reverberation time was developed by Wallace Sabine in 1898, for which he is considered to be the Father of Architectural Acoustics. He discovered a simple relationship where the time that sound lingers in a space (actually a drop of 60 dBA from the impulse to being unheard) is *directly proportional* to the cubic volume of the space and *inversely proportional* to the amount of sound absorption in the space. The *amount* of sound absorption is the *product* of the *surface area* (S) of each type of material in the space and that material's ability to absorb sound at various frequencies known as the *absorption coefficient* (α). The average of the coefficients in the middle frequencies yields a single-number value called the Noise Reduction Coefficient (NRC). Named for Wally, the *amount of sound absorption* is measured in *sabins* although it's just square feet. STC honors Wally by naming our panels *Hi-Sabin*.

All materials absorb, reflect or transmit sound energy, each at different proportional amounts. Sound isn't really *absorbed* like water in a sponge. In porous materials air molecules near the surface try to transfer their energy to molecules in the open crevices of the surface of the material. Friction with the walls of the crevices lowers the energy in the wave and thus the *intensity* of the sound power in the wave (loudness). Also, once the energy that returns from these crevices into the space it does so at different times because of the differing amounts of friction encountered. This destroys the *pattern* of air pressure variations in the reflected wave, which is really what sound is. The melamine-based foam of *STC Hi-Sabin™ Panels* has an *open cell* structure (lots of very small crevices) and is extremely efficient in the process of sound absorption. Most foams are *closed cell* and don't absorb sound, such as Styrofoam.

The sound absorption process works by exposing the material to the air molecules that comprise the sound wave. By furring or suspending the panel and spacing them apart there is more opportunity for the sound to be absorbed because the back and sides of the panel are exposed to the sound wave. The absorption coefficient is calculated by considering the ratio of the amount of sound *absorbed* compared to the amount *incident on the front surface area* of the panel. Since sound is also absorbed on the back and sides of the panel these coefficient values can rise above 1.0 – surprising because that means *more than 100%* of the sound energy *incident* on the panel is *absorbed*, a seemingly impossible physical task unless the measurement procedure is understood. (We really do give 110%).

The calculation of the amount of sound absorption needed in a space is fairly simple. Figure the number of cubic feet in the space (V), divide by the desired reverberation time in seconds (T), and multiply by 0.05 (a constant in seconds/foot related to the volume measurement in cubic feet and the 60-dBA drop figured by Sabine). This gives the number of sabins required ($\Sigma S\alpha$) to get the desired reverberation time. Figure the number of sabins (square feet x NRC) supplied by each of the other materials in the space on the walls and floor that are exposed to the sound. The difference between the *total sabins required* and the *sabins from other materials* is the number of sabins needed to be provided by the panels. Divide that value (required sabins to be supplied by the panels) by the NRC of the Hi-Sabin™ Panels selected and the total square feet area of panels required is obtained.

Face	Mounting	Thickness	Frequency						NRC
			125	250	500	1000	2000	4000	
Flat	A	1"	0.07	0.22	0.54	0.78	0.85	0.87	0.60
		1-1/2"	0.13	0.36	0.84	0.92	0.92	0.94	0.75
		2"	0.11	0.56	1.01	1.00	0.99	0.97	0.90
	F-50	1"	0.04	0.30	0.75	0.92	0.90	0.93	0.70
		1-1/2"	0.13	0.51	1.03	1.00	0.96	1.00	0.90
		2"	0.17	0.69	1.14	1.04	1.02	1.02	0.95
	J	1"	0.00	0.26	0.83	1.21	1.15	1.21	0.85
		1-1/2"	0.11	0.42	1.15	1.46	1.26	1.37	1.05
		2"	0.11	0.61	1.47	1.57	1.44	1.46	1.25
Patterned	A	1-1/2"	0.08	0.25	0.67	0.84	0.86	0.90	0.65
	F-50	1-1/2"	0.07	0.36	0.87	0.96	0.92	0.99	0.80
	J	1-1/2"	0.05	0.29	0.95	1.31	1.22	1.32	0.95

Values in the chart above for Type “A” Mounting are for direct-adhered panels butted together. Type “F-50” Mounting values are for panels mounted on 2-inch-high standoffs and butted together. Type “J” Mounting values are for panels mounted on standoffs and spaced apart in a pattern.

Controlling reverberation time only controls the reverberant sound energy in a space. People will still hear the sound that comes *directly* from a source in the same space, such as from other people in the vicinity that they may not want to hear. The direct sound level will only diminish with distance from the source. For that reason, the density (area per occupant) of patrons in a restaurant, for example, is just as important a consideration as reverberation time for achieving acoustical comfort.